



# Land Rover Series III

## Repair Operation Manual

AKM3648 (EDITION 4)



PDF by roby65to




BY APPOINTMENT TO HER MAJESTY THE QUEEN  
BL CARS LIMITED - BIRMINGHAM  
MANUFACTURERS OF ROVER CARS, LAND-ROVERS,  
RANGE ROVERS AND AUSTIN CARS



BY APPOINTMENT TO HER MAJESTY QUEEN ELIZABETH  
THE QUEEN MOTHER  
BL CARS LIMITED - COVENTRY AND BIRMINGHAM  
MANUFACTURERS OF DAIMLER, JAGUAR AND ROVER CARS  
AND LAND-ROVERS



BY APPOINTMENT  
TO H.R.H. THE PRINCE OF WALES  
LAND ROVER LIMITED - SOLIHULL  
MANUFACTURERS OF MOTOR VEHICLES



# LAND ROVER

## Series III

### REPAIR OPERATION MANUAL INCORPORATING FIVE MAIN BEARING ENGINE SUPPLEMENT

Published by  
**Land Rover Ltd**

A Managing Agent for Land Rover UK Limited  
PUBLICATION No. AKM3648 (EDITION 4)

Land Rover Limited  
Lode Lane  
Solihull  
West Midlands B92 8NW  
England

### **SPECIFICATION**

Land Rover Limited is constantly seeking ways to improve the specification of its vehicles and alterations take place continually. While every effort is made to produce up-to-date literature this Manual should not be regarded as an infallible guide to current specifications. Further the specification details set out in the Manual apply to a range of vehicles and not to any particular one.

Distributors and Dealers are not agents of Land Rover Limited and have absolutely no authority to bind Land Rover Limited by any express or implied undertaking or representation.

### **COPYRIGHT**

© Land Rover Limited 1981

## INTRODUCTION

The purpose of this manual is to assist skilled mechanics in the efficient repair and maintenance of the range of vehicles given on the title-page. The procedures detailed, carried out in the sequence given and using the appropriate service tools, will enable the operations to be completed in the time stated in the Repair Operation Times.

### Indexing

The content pages list the titles and reference numbers of the divisions in alphabetical order.

### Operation Numbering

Each operation is followed by the number allocated to it in a master index. The number consists of six digits arranged in three pairs.

The master index of operations has been compiled for universal application to vehicles manufactured by British Leyland Motor Corporation and therefore continuity of the numbering sequence is not maintained throughout the manual.

Each instruction within an operation has a sequence number, and to complete the operation in the minimum time it is essential that these instructions are performed in numerical sequence commencing at 1 unless otherwise stated. Where applicable, the sequence numbers identify the components in the appropriate illustration.

Where performance of an operation requires the use of a service tool, the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use.

An illustrated list of all service tools necessary to complete the operations described in the manual is also included.

### References

References to the left- or right-hand side in the manual are made when viewing the vehicle from the rear. With the engine and gearbox assembly removed, the water pump end of the engine is referred to as the front.

To reduce repetition, operations covered in this manual do not include reference to testing the vehicle after repair. It is essential that work is inspected and tested after completion and if necessary a road test of the vehicle is carried out particularly where safety related items are concerned.

### Dimensions

The dimensions quoted are to design engineering specification. Alternative unit equivalents, shown in brackets following the dimensions, have been converted from the original specification.

During the period of running-in from new, certain adjustments may vary from the specification figures given in this Manual. These adjustments will be re-set by the Distributor or Dealer at the After Sales Service, and thereafter should be maintained at the figures specified in the Manual.

## REPAIRS AND REPLACEMENTS

When replacement parts are required it is essential that only genuine Land Rover replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories:

Safety features embodied in the vehicle may be impaired if other than genuine Land Rover replacements are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification. Torque wrench setting figures given in the Repair Operation Manual must be strictly adhered to. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be renewed. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin. The terms of the Owners Service Statement may be invalidated by the fitting of other than genuine Land Rover parts.

All genuine Land Rover replacements have the full backing of the Owners Service Statement.

Land Rover Distributors and Dealers are obliged to supply only genuine Land Rover service parts.

## POISONOUS SUBSTANCES

### WARNING

Many liquids and other substances used in motor vehicles are poisonous and should under no circumstances be consumed and should as far as possible be kept away from open wounds. These substances among others include antifreeze, brake fluid, fuel, windscreen washer additives, lubricants and various adhesives.

## FUEL HANDLING PRECAUTIONS

The following information provides basic precautions which must be observed if petrol (gasoline) is to be handled safely. It also outlines the other areas of risk which must not be ignored.

This information is issued for basic guidance only, and in any case of doubt appropriate enquiries should be made of your local Fire Officer.

### General

Petrol/gasoline vapour is highly flammable and in confined spaces is also very explosive and toxic.

When petrol/gasoline evaporates it produces 150 times its own volume in vapour, which when diluted with air becomes a readily ignitable mixture. The vapour is heavier than air and will always fall to the lowest level. It can readily be distributed throughout a workshop by air current, consequently, even a small spillage of petrol/gasoline is potentially very dangerous.

Always have a fire extinguisher containing FOAM CO<sub>2</sub> GAS, or POWDER close at hand when handling or draining fuel, or when dismantling fuel systems and in areas where fuel containers are stored.

Always disconnect the vehicle battery BEFORE carrying out dismantling or draining work on a fuel system.

Whenever petrol/gasoline is being handled, drained or stored, or when fuel systems are being dismantled all forms of ignition must be extinguished or removed, any head-lamps used must be flameproof and kept clear of spillage.

**NO ONE SHOULD BE PERMITTED TO REPAIR COMPONENTS ASSOCIATED WITH PETROL/GASOLINE WITHOUT FIRST HAVING HAD SPECIALIST TRAINING.**

### Fuel Tank Draining

**WARNING: PETROL/GASOLINE MUST NOT BE EXTRACTED OR DRAINED FROM ANY VEHICLE WHILST IT IS STANDING OVER A PIT.**

Draining or extracting petrol/gasoline from vehicle fuel tank must be carried out in a well ventilated area.

The receptacle used to contain the petrol/gasoline must be more than adequate for the full amount of fuel to be extracted or drained. The receptacle should be clearly marked with its contents, and placed in a safe storage area which meets the requirements of local authority regulations.

**WHEN PETROL/GASOLINE HAS BEEN EXTRACTED OR DRAINED FROM A FUEL TANK THE PRECAUTIONS GOVERNING NAKED LIGHTS AND IGNITION SOURCES SHOULD BE MAINTAINED.**

### Fuel Tank Removal

On vehicles where the fuel line is secured to the fuel tank outlet by a spring steel clip, it is recommended that such clips are released before the fuel line is disconnected or the fuel tank unit is removed. This procedure will avoid the possibility of residual petrol fumes in the fuel tank being ignited when the clips are released.

As an added precaution fuel tanks should have a PETROL/GASOLINE VAPOUR warning label attached to them as soon as they are removed from the vehicle.

*continued*

# WEIGHTS

## Short-wheelbase weights

	Full Length Canvas Hood				Truck Cab				Hard Top				Station Wagon				
	Petrol		Diesel		Petrol		Diesel		Petrol		Diesel		Petrol		Diesel		
	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	
<b>UNLADEN WEIGHT</b>																	
Front axle .....	718	1583	747	1647	725	1599	754	1663	713	1572	742	1636	705	1555	734	1619	
Rear axle .....	580	1279	589	1299	582	1283	591	1303	625	1378	634	1398	713	1572	722	1592	
Total .....	1298	2862	1336	2946	1307	2882	1345	2966	1338	2950	1376	3034	1418	3127	1456	3211	
<b>EEC KERB WEIGHT</b>																	
Front axle .....	756	1667	786	1733	763	1682	793	1749	751	1656	781	1722	743	1638	773	1705	
Rear axle .....	650	1433	661	1457	652	1438	663	1462	695	1532	706	1557	783	1727	794	1751	
Total .....	1406	3100	1447	3190	1415	3120	1456	3211	1446	3188	1487	3279	1526	3365	1567	3456	
<b>GROSS VEHICLE WEIGHT</b>																	
Front axle .....	930 2051		930 2051		930 2051		930 2051		930 2050		930 2050		930 2050		930 2050		
Rear axle .....	1190 2624		1190 2624		1190 2624		1190 2624		1190 2624		1190 2624		1190 2624		1190 2624		
Total .....	2120 4675		2120 4675		2120 4675		2120 4675		2120 4674		2120 4674		2120 4674		2120 4674		

**NOTE:** Unladen weight is the minimum vehicle specification—excluding fuel and driver.  
 EEC kerb weight is the minimum vehicle specification—plus full fuel tank and 75 kg (165 lb) driver.  
 Gross vehicle weight is the maximum all-up weight including driver, passengers, payload and equipment.

**NOTE:** For sustained cross-country use the gross vehicle weight must be reduced by 90 kg (off the rear axle).

Maximum Permissible Towed Weights	On-road		Off-road	
	kg	lb	kg	lb
Trailers without brakes .....	500	1100	500	1100
Trailers with over-run brakes .....	2000	4400	1000	2200
4-wheel trailers with continuous or semi-continuous brakes, i.e. coupled brakes .....	(Petrol) 3500 7700		(Diesel) 1000 2200	

**NOTE:** The weights above do not authorise use outside the legislation enforced by the territory in which the vehicle and trailer combination is being operated.

## Long-wheelbase weights

	Full Length Canvas Hood				Truck Cab				Hard Top				12-seater Station Wagon				2710 kg Gross vehicle weight		3020 kg Gross vehicle weight	
	4-cylinder Petrol		4-cylinder Diesel		4-cylinder Petrol		4-cylinder Diesel		4-cylinder Petrol		4-cylinder Diesel		4-cylinder Petrol		4-cylinder Diesel		4-cylinder Petrol	4-cylinder Diesel		
	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	lb	kg	kg		
<b>UNLADEN WEIGHT</b>																				
Front axle .....	785	1733	814	1795	794	1751	823	1815	786	1733	815	1797	788	1797	819	1806	799	812	818	831
Rear axle .....	700	1544	712	1570	694	1530	706	1557	744	1641	756	1667	891	1965	890	1962	720	732	744	756
Total .....	1485	3277	1526	3365	1488	3281	1529	3372	1530	3374	1571	3464	1679	3702	1709	3768	1519	1544	1562	1587
<b>EEC KERB WEIGHT</b>																				
Front axle .....	811	1788	839	1850	820	1808	848	1870	812	1790	840	1852	814	1795	844	1861	825	837	844	856
Rear axle .....	798	1760	819	1806	792	1746	813	1793	842	1857	863	1903	989	2181	997	2198	818	839	842	863
Total .....	1609	3548	1658	3656	1612	3554	1661	3663	1654	3647	1703	3755	1803	3976	1841	4059	1643	1676	1686	1719
<b>GROSS VEHICLE WEIGHT</b>																				
Front axle .....	1000 2205		1000 2205		1000 2205		1000 2205		1000 2205		1000 2205		1000 2205		1000 2205		1000		1120	
Rear axle .....	1710 3771		1710 3771		1710 3771		1710 3771		1710 3771		1710 3771		1710 3771		1710 3771		1710		1900	
Total .....	2710 5976		2710 5976		2710 5976		2710 5976		2710 5976		2710 5976		2710 5976		2710 5976		2710		3020	

## High Capacity Pick-Up Weights

## ENGINE TUNING DATA

### ENGINE

2¼ litre 4-cylinder Petrol models (Refer to Division 17 for emission controlled engines)

Type .....	In line four cylinder four stroke, overhead valves
Capacity .....	2286 cm <sup>3</sup> (139.5 in. <sup>3</sup> ).
Compression ratio	
Standard .....	8.0:1 (Engine number commencing 901....)
Optional .....	7.0:1 (Engine number commencing 904....)
Firing Order .....	1-3-4-2
Compression pressure	
8.0:1 compression ratio .....	11,2 kgf. cm <sup>2</sup> (160 lbf. in. <sup>2</sup> )
7.0:1 compression ratio .....	10,2 kgf. cm <sup>2</sup> (145 lbf. in. <sup>2</sup> )
Idling speed .....	500 rev/min
Fast idle setting .....	1,40 mm (0.055 in.) throttle butterfly clearance, 1200 ± 50 rev/min
Ignition timing, static	
8.0:1 compression ratio .....	TDC when using 90 octane fuel 3° ATDC when using 85 octane fuel
7.0:1 compression ratio .....	3° BTDC when using 83 octane fuel TDC when using 75 octane fuel
Timing marks .....	On crankshaft pulley
Valve clearance, inlet and exhaust .....	0,25 mm (0.010 in.)

### DISTRIBUTOR

Make/type .....	Lucas 45D
Rotation of rotor .....	Anti-clockwise
Contact breaker gap .....	0,36 mm to 0,40 mm (0.014 in. to 0.016 in.)
Condenser capacity .....	0.2 microfarad
Serial number .....	5069

Centrifugal advance with TDC ignition timing

Decelerating check with vacuum unit disconnected

Crankshaft angle	Engine rev/min
38° to 42°	4500
30° to 34°	3500
22° to 26°	2500
12° to 16°	1200
4° to 12°	900
0° to 4°	600
No advance below	450

### Vacuum advance

Starts .....	89 mm (3.5 in.) Hg.
Finishes .....	635 mm (25.0 in.) Hg.

### SPARKING PLUGS

Make/type	
8.0:1 compression ratio .....	Champion N12Y or Unipart GSP 131
7.0:1 compression ratio .....	Champion N8 or Unipart GSP 130
Gap .....	0,75 to 0,80 mm (0.029 to 0.032 in.)

### IGNITION COIL

Make/type .....	HA12
Primary resistance at 20°C (68°F) .....	3.0 to 3.5 ohms
Consumption—ignition on at engine idle speed .....	2.0 amps approx.

### CARBURETTER

Make/type .....	Zenith 361V
Choke diameter .....	27 mm
Main jet .....	125
Compensating (enrichment) jet .....	150
Pump jet .....	65 (short stroke, outer hole)
Needle valve .....	1.75

### High altitude carburetter

Main (120) .....	Altitude: 1524 to 2133 m (5000 to 7000 ft)
(117.5) .....	2133 to 2743 m (7000 to 9000 ft)
(115) .....	2743 to 3657 m (9000 to 12000 ft)
(112.5) .....	3657 to 4267 m (12000 to 14000 ft)
Slow running (55) .....	2743 to 4267 m (9000 to 14000 ft)

### ENGINE

2¼ litre 4-cylinder Diesel models

Type .....	In line four cylinder four stroke, overhead valves
Capacity .....	2286 cm <sup>3</sup> (139.5 in. <sup>3</sup> )
Compression ratio .....	23.0:1
Firing order .....	1-3-4-2
Idling speed .....	590 ± 20 rev/min
Injection timing setting .....	13° B.T.D.C.
Timing marks	
Valve timing — inlet and exhaust .....	
Injection timing .....	On engine flywheel and pump flange
Valve clearance — inlet and exhaust .....	0,25 mm (0,010 in)

### INJECTORS

Make/type .....	CAV Pintaux
Nozzle size .....	BDNO/SPC 6209
Opening pressure .....	135 Atm

### HEATER PLUGS

Make/type .....	KLG GF 210/T or Champion AG45
-----------------	-------------------------------

### DISTRIBUTOR PUMP

Make/type .....	CAV type DPA
Direction of rotation .....	Clockwise, viewed from drive end
Maximum speed setting (sealed) .....	4,200 engine rev/min


**(12) Fan belt adjustment**

**4 cylinder models:**

- 1 Check by thumb pressure between the fan and crankshaft pulleys. Movement should be 6,3 to 9,5 mm (0.25 to 0.375 in.)

**If necessary adjust as follows:**

- 2 Slacken the pivot bolt securing the alternator to the mounting bracket.
- 3 Slacken the adjusting bolt.
- 4 Pivot the alternator inwards or outwards as necessary and adjust until the correct belt tension is obtained.
- 5 Tighten adjusting and pivot bolts.




**6-cylinder models:**

- 6 Check by thumb pressure between the fan and crankshaft pulleys. Movement should be 8 to 11 mm (0.312 to 0.437 in.) Adjust as above.

**Air pump drive belt adjustment, 6-cylinder models**

- 1 Check by thumb pressure midway between the air pump and water pump pulleys. Movement should be 6,3 mm (0.25 in.). If necessary, adjust as follows:
- 2 Slacken the pivot bolts securing the air pump to the top mounting bracket.
- 3 Slacken the nut and bolt securing the air pump to the adjustment bracket.
- 4 Pivot the air pump as necessary and adjust until the correct belt tension is obtained.
- 5 Tighten the adjusting and pivot bolts and nuts.



**(13) Accelerator linkage—all Models**

- 1 Lubricate the accelerator linkage using clean engine oil paying particular attention to accelerator cross craft brackets, bell crank bushes and ball joint sockets on the control rods.
- 2 Check the linkage for correct operation and ensure that there is no tendency to stick. Badly worn parts should be replaced as soon as possible.


**(14) Engine mountings**

Check security of engine mountings; rectify as necessary. Engine sump bolts, see operation 12.60.44.

**(15) Engine breather filters—all Models**

Clean as follows:


- 1 Remove the filters.
- 2 Wash the gauze thoroughly by swilling the units in petrol.
- 3 Re-wet the gauzes by dipping in clean engine oil and shake off the surplus; 4-cylinder models, replace the engine breather filter with the slot facing forward and the oil filler filter with the slot facing the rear of the vehicle.
- 4 Models with sealed engine breather system. Connect hose to top breather.



**(16) Crankcase emission control, flame-trap type (as applicable)**

Replace as follows:

- 1 Detach the rubber hoses from each side of the flame trap by compressing the clips.
- 2 Withdraw flame trap.
- 3 Fit new flame trap by reversing removal procedure.
- 4 Warm up engine and re-adjust carburetter if necessary.






## KEY TO ILLUSTRATION OF ACCELERATOR CONTROLS, 2¼ LITRE DIESEL MODELS

- 1 Housing for accelerator shaft and pedal stop
- 2 Bolt (¼ in. UNF X ½ in. long) Fixing housing
- 3 Spring washer and pedal stop
- 4 Nut (¼ in. UNF) to dash
- 5 Bracket for accelerator pedal shaft
- 6 Bolt (¼ in. UNF X ⅝ in. long)
- 7 Plain washer Fixing bracket
- 8 Spring washer to dash
- 9 Nut (¼ in. UNF)
- 10 Shaft for accelerator pedal
- 11 Accelerator pedal
- 12 Bolt (⅝ in. UNF X ⅞ in. long) Fixing pedal
- 13 Nut (⅝ in. UNF) to shaft
- 14 Bolt (⅝ in. UNF X 2½ in. long) Pedal
- 15 Plain washer stop in
- 16 Nut (⅝ in. UNF) floor
- 17 Lever for accelerator on pedal shaft
- 18 Bolt (¼ in. UNF X 1¼ in. long) Fixing lever
- 19 Nut (¼ in. UNF) to shaft
- 20 Return spring for pedal
- 21 Anchor for return spring
- 22 Bracket for accelerator cross-shaft
- 23 Bolt (¼ in. UNF X ⅝ in. long) Fixing
- 24 Spring washer brackets
- 25 Nut (¼ in. UNF) to dash
- 26 Accelerator cross-shaft
- 27 Stop clip for cross-shaft
- 28 Accelerator lever on cross-shaft from pedal
- 29 Distance washer for cross-shaft
- 30 Bolt (¼ in. UNF X 1¼ in. long) Fixing levers and
- 31 Nut (¼ in. UNF) stop clip to cross-shaft
- 32 Control rod, pedal shaft to cross-shaft
- 33 Ball joint socket For
- 34 Locknut (2 BA) rod
- 35 Control rod, pedal shaft to cross shaft
- 36 Linkage clip for control rod
- 37 Control rod, bell crank to accelerator lever
- 38 Ball socket
- 39 Nut (2 BA) For bell crank control rod
- 40 Adjuster nut
- 41 Return spring for accelerator and stop levers on
- 42 Anchor for return spring distributor pump
- 43 Accelerator lever on cross-shaft to engine
- 44 Control rod, cross-shaft to bell crank
- 45 Ball joint For
- 46 Locknut (2 BA) control rod
- 47 Control rod, cross-shaft to bell crank
- 48 Linkage clip for control rod
- 49 Bracket for bell crank on distributor pump
- 50 Spring washer Fixing bracket to
- 51 Nut (10 UNF) distributor pump

- 52 Bell crank complete on distributor pump
- 53 Bush for bell crank
- 54 Ball end for bell crank
- 55 Pin for bell crank
- 56 Shakeproof washer Fixing pin to bell
- 57 Nut (¼ in. UNF) crank bracket
- 58 Plain washer Fixing bell crank
- 59 Split pin lever to pin
- 60 'Engine stop' control
- 61 Clip Fixing control outer cable
- 62 Screw (2 BA X ⅝ in. long) to abutment bracket



## SWIVEL PIN HOUSING ASSEMBLY

Remove and refit

60.15.20



Service tool. 601763. Ball joint extractor.

### Removing

- 1 Remove the front hub. 60.25.01.
- 2 Remove the front stub axle. 60.25.22.
- 3 Withdraw the half shaft.
- 4 Disconnect the track rod at the track arm; tool 601763. If the swivel housing to be removed is fitted to the steering box side of the vehicle disconnect the drag link.
- 5 Remove the bolts and nuts securing the inner flange of the swivel housing assembly to the axle flange. Note the location of the steering stop bracket, and, on the right hand flange only, the position of the jack location stop bracket.
- 6 Remove the swivel pin housing assembly.
- 7 Remove and discard the inner flange gasket.

### Refitting

- 8 Reverse instructions 1 to 7. Torque – track rod end nut 4,0 kfg. m (30 lbf. ft.).



## SWIVEL PIN HOUSING ASSEMBLY

Overhaul





60.15.23

- 1 Remove the swivel pin housing assembly from the vehicle 60.15.20

### Dismantling


- 2 Remove the bolts, spring and plain washers securing the inboard oil seal cover. Note the position of the steering stop bracket, brake hose bracket, and if the swivel unit is fitted to the right hand side of the vehicle, the position of the jack location plate. Withdraw the oil seal cover.
- 3 Prise out and discard the oil seal.
- 4 Release the lock tabs from the upper swivel pin bolts and remove the bolts and lock plates.
- 5 Withdraw the upper swivel pin and shims.
- 6 Release the lock tabs from the track arm nuts and remove the nuts and lock plates.
- 7 Withdraw the track arm complete with the lower swivel pin. Remove and discard the 'O' ring.
- 8 Separate the swivel pin inner and outer housings.
- 9 Remove the lower swivel pin roller bearing and bearing track.
- 10 Press out the Railko bush housing.
- 11 Remove the half shaft bearing track.

*continued*



### Key to hand brake lever arrangement LH Steering

- |    |                             |    |                   |
|----|-----------------------------|----|-------------------|
| 1  | Housing—cross shaft bearing | 24 | Clevis pin        |
| 2  | Bolts                       | 25 | Fork—clevis       |
| 3  | Spring washer               | 26 | Split pin         |
| 4  | Felt ring                   | 27 | Spring anchor     |
| 5  | Bearing—cross shaft         | 28 | Nut               |
| 6  | Distance piece              | 29 | Rod               |
| 7  | Support plate               | 30 | Nut—self-locking  |
| 8  | Split pin                   | 31 | Clevis pin        |
| 9  | Pin—adjuster rod            | 32 | Split pin         |
| 10 | Plain washer                | 33 | Plain washer      |
| 11 | Spring washer               | 34 | Washer            |
| 12 | Bolt                        | 35 | Ratchet           |
| 13 | Cross shaft                 | 36 | Bolt              |
| 14 | Nut—self-locking            | 37 | Plain washer      |
| 15 | Plate washer                | 38 | Distance piece    |
| 16 | Washer                      | 39 | Pawl              |
| 17 | Shaft                       | 40 | Plunger rod—lower |
| 18 | Relay lever                 | 41 | Plunger rod—upper |
| 19 | Bush                        | 42 | Hand brake lever  |
| 20 | Washer                      | 43 | Washer            |
| 21 | Circlip                     | 44 | Spring            |
| 22 | Spring anchor               | 45 | Plunger           |
| 23 | Spring                      |    |                   |



0986



## TRANSMISSION BRAKE ASSEMBLY

Adjust. Instructions 36 to 39 70.45.09  
 Remove and refit Instructions 1 to 39 70.45.16


## TRANSMISSION BRAKE SHOES

Remove and refit Instructions 1 to 7, and 32 to 39 70.45.18


### Removing

**NOTE:** Brake shoe components are accessible after removing the brake drum, which can be detached from the gearbox output flange and pushed back over the propeller shaft.


- 1 Chock the road wheels.
- 2 Disconnect the brake return spring.
- 3 Remove the expander rod fork fixings.
- 4 Disconnect the expander rod from the relay lever, and remove the propeller shaft on the 109 in Land-Rover.
- 5 Remove the fixings and withdraw the brake drum.
- 6 Remove the brake shoes together with the pull-off springs.
- 7 Separate the shoes by detaching the springs.
- 8 Withdraw the dust excluder.
- 9 Remove the expander unit fixing plates.
- 10 Withdraw the expander unit.
- 11 Remove the spring clip from the expander unit.
- 12 Withdraw the plungers and rollers.
- 13 Withdraw the operating rod.
- 14 Remove the adjuster unit assembly.
- 15 Pull out the adjuster plungers.
- 16 Unscrew the adjuster cone.



IRC 737



IRC 738



IRC 739

### Inspecting


- 17 Clean all components in Girling cleaning fluid and allow to dry.
- 18 Examine all items for obvious wear and replace as necessary.
- 19 Examine the brake drum for scoring and ovality and skim if required. Standard diameter is 228,6 mm (9.0 in.); reclamation limit is 0,75 mm (0.030 in.) oversize.
- 20 If the brake linings are oily, check and if necessary replace the output shaft oil seal, Division 37.
- 21 If required, reline the brake shoes. 70.40.10.

### Assembling


- 22 Fit the adjuster unit housing, do not tighten the fixings at this stage.
- 23 Screw in the adjuster cone.
- 24 Grease and refit the adjuster plungers.

**NOTE:** The two plungers are identical and may be fitted to either bore. Align the chamfered ends of the plungers with the cone on the adjuster.

*continued*






IRC 740



IRC 741

- 25 Grease and fit the expander rod.
- 26 Grease and fit the plungers and rollers.
- 27 Position the adjuster housing on the back plate.
- 28 Fit the packing piece.
- 29 Fit the locking plate.
- 30 Fit the retainer spring.
- 31 Fit the spring clip to the expander unit.
- 32 Fit the brake shoes and pull-off springs together.
- 33 The fully lined end of the lower shoe must be toward the expander housing.
- 34 The fully lined end of the upper shoe must be toward the adjuster housing.
- 35 Reverse instructions 2 to 5.
- 36 Turn the adjuster cone fully in and tighten the fixings.
- 37 Slacken off the adjuster cone two 'clicks'; give the brake a firm application to ensure that the shoes have centralised at the expander end. The brake drum should now be free to rotate.
- 38 Set the hand brake linkage at the vertical adjuster rod, so that the hand brake has one or two clicks free movement in the 'off' position.
- 39 Remove the road wheel chocks.



### SERVO ASSEMBLY


Remove and refit 70.50.01

#### Removing

- 1 Remove the brake master cylinder. 70.30.01 or 70.30.08 as applicable.
- 2 Disconnect the vacuum hose from the servo assembly.
- 3 Remove the switch plate.
- 4 Remove the rubber plugs from the pedal box.
- 5 Remove the split pin and withdraw the clevis pin securing the servo rod to the pedal.
- 6 Remove the fixings.
- 7 Withdraw the servo assembly.

#### Refitting

- 8 Reverse instructions 1 to 7. Torque load for servo fixings is 1,2 kgf. m. (9 lbf. ft.).



### VACUUM RESERVOIR TANK — Diesel models with Servo


Remove and refit 70.50.04


#### Removing

- 1 Remove the union bolt and washers securing the vacuum pipes to the vacuum tank.
- 2 Remove the bolts, washers and nuts securing the vacuum tank brackets to the vehicle.
- 3 Withdraw the vacuum tank and brackets from the vehicle.
- 4 Remove the brackets from the vacuum tank.

#### Refitting


- 5 Reverse instructions 1 to 4.





Door - rear - 109 station wagon  
Key

- |                        |                  |
|------------------------|------------------|
| 1 Seal - window catch  | 10 Retainer      |
| 2 Mask - window catch  | 11 Channel       |
| 3 Window catch         | 12 Filler        |
| 4 Retainer             | 13 Packing strip |
| 5 Filler               | 14 Channel       |
| 6 Buffer               | 15 Channel       |
| 7 Channel              | 16 Packing strip |
| 8 Sealing rubber       | 17 Rear door     |
| 9 Door glass - sliding |                  |



Tail door - station wagon  
Key

- |                                 |                                  |
|---------------------------------|----------------------------------|
| 1 Seal                          | 7 Glass retainer strip - side    |
| 2 Seal retainer                 | 8 Arch-hard top                  |
| 3 Protection strip              | 9 Sealing rubber                 |
| 4 Rear door                     | 10 Glass retainer - corner piece |
| 5 Glass retainer strip - bottom | 11 Glass retainer strip - top    |
| 6 Glass                         | 12 Seal                          |



## SIDE DOOR GLASS

Front door 76.31.01  
Rear door 76.31.02

### Remove and refit

#### Removing

##### Sliding glass

- 1 Remove the screw and rubber stop from the front end of the sliding glass top channel. Remove the remaining channel securing screws.
- 2 Incline the sliding glass inwards complete with top channel and the filler strip.
- 3 Remove the channel and filler strip.
- 4 Lift out the sliding glass.

##### Fixed glass

- 5 Remove the sliding glass (instructions 1 to 4 above).
- 6 Remove the front angle strip.
- 7 Carefully release the fixed glass from the sealing compound.
- 8 Withdraw the fixed glass.
- 9 Remove the old sealing compound from glass and door.


#### Refitting

##### Fixed glass

- 10 Apply fresh sealing compound to the door frame.
- 11 Carefully insert the fixed glass and press firmly into position. Remove surplus sealing compound.
- 12 Fit the front angle sealing strip.

##### Sliding glass

- 13 Fit the sliding glass, top channel and filler strip in reverse order to instructions 1 to 4.



0912

## DOOR LOCK


Remove and refit  
Side door, front 76.37.12  
Side door, rear 76.37.13  
Tail door 76.37.16

#### Removing


- 1 Remove the door trim where fitted.
- 2 Remove the screws securing the lock to the door edge (not anti-burst type).
- 3 Remove the two screws securing the top of the lock to the door.
- 4 Remove the tapped plate.
- 5 Remove the nuts securing the bottom of the lock to the door.
- 6 Remove the studplate.
- 7 Remove the door lock and sealing plate. (Sealing plates are not fitted to anti-burst type locks.)

#### Refitting

- 8 Reverse instructions 1 to 7.



0925



4RC 932

### FASCIA TOP RAIL

Remove and refit 76.46.04


#### Removing

- 1 Remove the screws securing the fascia top rail end cover and heater control. Ease the end cover aside.
- 2 Remove the screws securing the fascia top rail end cover (passenger's side). Withdraw the end cover.

- 3 Remove the two nuts and bolts securing the rear of the fascia top rail to the fascia mounting plate.
- 4 Remove the screws securing the demist outlets. Withdraw the demist outlets.
- 5 Remove the screws securing the front of the fascia top rail.
- 6 Remove the top rail.

#### Refitting

- 7 Reverse instructions 1 to 6.



### LOWER FASCIA

Remove and refit 76.46.05


#### Removing

- 1 Release the shroud from the steering column and the lower fascia.
- 2 Remove the heater control panel from the driver's end of the fascia and disconnect the distribution control cable.
- 3 Withdraw the instrument panel clear of the dash.
- 4 Withdraw the demister hoses.
- 5 Withdraw the finisher strip from the top edge of the lower fascia.

- 6 If the vehicle is fitted with auxiliary instruments at the centre of the lower fascia, remove as applicable.
- 7 Remove the end cover from the lower fascia.
- 8 Remove the parcel tray.
- 9 Remove the fixings securing the lower fascia to the dash.
- 10 Withdraw the lower fascia.
- 11 If required, remove the heater duct cover and the distribution flap valves, as applicable.

#### Refitting


- 12 Reverse instructions 1 to 11. Where applicable, ensure that the gasket is fitted between the heater duct and the dash.



### AIR DISTRIBUTION FLAPS

Remove and refit 80.15.09

This operation is described in operation 80.10.06.



1RC994

### VENTILATOR GRILLE PANEL


Remove and refit 80.15.16

#### Removing

- 1 Remove the hinge pins.
- 2 Remove the control lever fixings.
- 3 Remove the ventilator control to dash fixings.
- 4 Withdraw the ventilator control and quadrant assembly.

#### Refitting

- 5 Check the lever operation in the quadrant. If required, adjust the special locknut to alter the spring loading on the lever.
- 6 Reverse instructions 1 to 4.



1RC995

### FRESH AIR INTAKE


Remove and refit 80.15.29

#### Removing

- 1 Remove the fixings.
- 2 Withdraw the intake grille assembly.
- 3 If required, withdraw the air inlet seal.

#### Refitting

- 4 Reverse instructions 1 to 3.



1RC 992

### HEATER BOX COMPLETE

Remove and refit 1 to 7, 12 & 13 80.20.01

### HEATER RADIATOR


Remove and refit 1 to 13 80.20.29

#### Removing


- 1 From inside the cab remove the trim board rail, if fitted.
- 2 Withdraw the trim board from the clip, if fitted.
- 3 Remove the heater box lower fixings.
- 4 Disconnect the heater water hoses.
- 5 Disconnect the air inlet hose.
- 6 Remove the heater box upper fixings.
- 7 Withdraw the heater box.
- 8 If removal of the heater radiator is required, proceed as follows, instructions 9 and 10.
- 9 Remove the fixings and withdraw the detachable side panel.
- 10 Withdraw the radiator and pipes assembly.

#### Refitting


- 11 If the heater radiator was removed reverse instructions 9 and 10.
- 12 Ensure that the joint seal is present and sound.
- 13 Reverse instructions 1 to 7.



1RC985



1RC986



1RC 987



### HEATER/BLOWER FAN MOTOR



Remove and refit 80.20.15

#### Removing

- 1 Disconnect the battery.
- 2 Disconnect the blower motor leads.
- 3 From inside the cab remove the trim board rail.
- 4 Withdraw the trim board from the clip.
- 5 Remove the blower motor fixings.
- 6 Disconnect the air hose at the matrix inlet.
- 7 Remove the wing panel rear top fixing bolt.
- 8 Manoeuvre the blower motor assembly clear, lifting the wing panel sufficient to allow passage.
- 9 Withdraw the air inlet seal.

#### Refitting

- 10 Fit the blower motor but omit the air inlet seal at this stage.
- 11 Remove the air intake grille.
- 12 Fit the air inlet seal and replace the intake grille.
- 13 Reverse 2 to 7. Connect the electrical leads from the blower motor at the snap connectors as follows: Brown lead with green marker band - to green/slate lead; green/yellow lead - to green/yellow lead.



### HEATER PIPES



Remove and refit  
 Feed to heater 80.25.15  
 Return from heater 80.25.16

#### Removing


- 1 Partially drain the coolant.
- 2 Disconnect the hoses.
- 3 Remove the fixings and withdraw the pipe.

#### Refitting


- 4 Reverse instructions 1 to 3.




**SERVICE TOOLS  
ENGINE**




**246650. Cylinder liner press block (2.6 Petrol)**




**271482. Injector cap spanner (2 1/4 Diesel)**




**274400. Drift—inlet valve guide**




**261288. Reboring jig block (2.6 Petrol)**




**271483 (18G 109A). Test gauge—injector (2 1/4 Diesel)**




**274401. Drift—exhaust valve guide**




**262749. Extractor—side rocker shaft (2.6 Petrol)**




**274389. Reamer—camshaft bearings (2 1/4 Engines)**




**276102 (18G 106). Valve spring compressor**



**270304. Guide—rear bearing cap seals**



**274399. Drift-push rod tube and injector shroud (2 1/4 Diesel)**



**278181. Injector—nozzle flushing tool (2 1/4 Diesel)**

*continued*

## INTRODUCTION

This supplement must be used in conjunction with the current Land Rover Series III Repair Operation Manual.

The introduction of a five main bearing crankshaft to the 2¼ litre petrol and diesel engine has caused changes to some repair operations. The operations concerned have been revised and are included in this publication together with details of the differences between the new engines and the existing three bearing units.

Since the new petrol engine is manufactured at different plants, some variations exist and for purposes of identification two commencing serial numbers have been allocated namely 36100001A and 99100001A. The diesel engine commencing number is 36600001A.

Set out below are the principal differences between the three and five main bearing petrol engines and the variations between the two five main bearing units. Parts common to diesel engine serial number range 36600001A are also mentioned.

### Crankshaft

Redesigned to include five main bearings. The main bearing journal and crankpin dimensions remain the same as for the three bearing shaft. The five bearing shaft fitted to commencing serial number range 36100001A is a casting whereas a forged shaft is used in serial number range 99100001A and the diesel engine. Whilst a cast crankshaft must not be fitted to engines in serial range 99100001A and the diesel version a forged may be used in serial number range 36100001A. Forged crankshafts, however, will only be supplied for spares.

### Cylinder Block

Redesigned to accommodate five main bearings. Sealing of the rear main bearing changed to a lip type seal pressed into the flywheel housing. The outside diameter of the crankshaft flange runs in the seal. The relevant repair operations have been revised and included in this supplement.

### Camshaft

The valve timing of the camshaft fitted to the engine serial number range 36100001A is as follows.

Inlet opens	6° BTDC
Inlet closes	52° ABDC
Inlet peak	113° ATDC
Exhaust opens	34° BBDC
Exhaust closes	24° ATDC
Exhaust peak	95° BTDC

Number one exhaust cam peak is on the centre line of camshaft keyway.

The camshaft sprocket retaining bolt has a UNF thread.

Valve timing for the camshaft fitted to serial number range 99100001A and diesel engine number range 36600001A is:

Inlet opens	16° BTDC
Inlet closes	42° ABDC
Inlet peak	103° ATDC
Exhaust opens	51° BBDC
Exhaust closes	13° ATDC
Exhaust peak	109° BTDC

Number one exhaust cam peak on the camshaft fitted to serial number range 99100001A is 7° to the right of the keyway centre line viewed from the keyway end.

The camshaft sprocket retaining bolt has a metric thread.

### Oil Pump

Interchangeable as an assembly between serial number range 36100001A and 99100001A. The pump gears, although different, are interchangeable with either assembly provided the gears are fitted as a matched set. The pump is interchangeable on serial number range 36100001A. The idler gear and the driver are both steel on serial number range 99100001A. On serial number range 36100001A the idler is aluminium and the driver steel.



## INTRODUCTION

### Flywheel


Design change to fit five main bearing crankshaft flange. Interchangeable between serial number ranges 36100001A and 99100001A but not with diesel engine range 36600001A.

### Flywheel Housing

Design change to accommodate new crankshaft and rear main bearing oil seal arrangement. Interchangeable between serial number ranges 36100001A and 99100001A but not with diesel engine range 36600001A.

### Timing Chain Tensioner


The timing chain tensioner assembly is the same as used on the three main bearing versions. The assembly fitted to serial number range 99100001A is the same as that used on diesel engine range 36600001A. The tensioner fitted to early petrol engine range 36100001A has a different piston assembly incorporating a relief valve. This has now been discontinued and all three engines now have the same tensioner. The ratchet on serial number range 99100001A is different in appearance and method of manufacture but dimensionally the same.



LR 667

**99100001A and 36600001A  
engine serial no. range**

1. Ratchet
2. Pawl
3. Cylinder
4. Spring
5. Ratchet pivot and retaining bolt
6. Ratchet return spring
7. Jockey sprocket
8. Retaining clip for ball
9. Ball



LR 666

**36100001A engine serial no. range  
(Early engines only)**

1. Ratchet
2. Pawl
3. Cylinder
4. Spring
5. Ratchet pivot and retaining bolt
6. Ratchet return spring
7. Jockey sprocket
8. Relief valve spring
9. Relief valve ball
10. Relief valve plug
11. Piston assembly

## ELECTRICAL

### CONTACT BREAKER POINTS (Ducellier)

—Remove and refit

86.35.13

#### Special tool 18G1308

#### Removing



1. Release the spring clips and remove the distributor cap.
2. Pull off the rotor arm.
3. Remove the dust shield.
4. Remove the retaining screw and remove the fixed contact point.
5. Slide the spring clip rearwards.
6. Disconnect the suppressor lead from the connector block.
7. Disconnect the lead from ignition coil.
8. Remove insulation washer from the moving contact point.
9. Lift off the moving contact point complete with leads and connector block from the distributor body.

#### Refitting

10. Fit the new moving point over post.
11. Locate the leaf spring in the plastic guide.
12. Fit the insulation washer.
13. Secure the assembly with the spring clip.
14. Fit the connector block to the distributor body.
15. Connect ignition coil lead.
16. Fit suppressor lead to connector block.
17. Fit the fixed contact point and loosely retain with the screw.

**NOTE:** The following two instructions describe the adjustment of the contact points. The accompanying illustration shows it being done with the aid of special tool 18G1308. Whilst the points can be adjusted to the datum setting only (see data) without the tool full distributor adjustment, i.e. dwell angle, dwell variation and vacuum advance can only be achieved by using this tool in conjunction with engine diagnostic equipment. It is essential that the above adjustments are carried out in order to maintain correct emission levels and maximum engine efficiency.

18. Rotate the engine until a cam of the rotor fully opens the points.
19. Using a feeler, adjust the position of the fixed contact point to the datum setting and tighten the retaining screw.
20. Check and adjust the dwell angle, dwell variation and vacuum advance, see instructions 38 to 43 operation 86.35.26.





## ELECTRICAL

### Lubrication

**NOTE:** The following instructions should be carried out every 20,000km (12,000 miles) except instruction 20.

15. Clean and lightly grease the cam with Shell Retinax or equivalent and remove any surplus lubricant.
16. Using the same grease lubricate the underside of the heel actuator.
17. Grease the actuator ramps and contact breaker heel ribs.
18. Apply grease to the fixed pin and the actuator fork.
19. Apply a drop of clean engine oil to the felt pad underneath the rotor arm.
20. Every 40,000km (25,000 miles) lubricate the automatic advance mechanism by injecting one or two drops of engine oil through the aperture in the base plate.
21. Wipe the internal and external surfaces of the distributor cap with clean dry nap-free cloth and fit the cap to the distributor body.





## DISTRIBUTOR (Ducellier)

—Overhaul

86.35.26

## Special tool 18G1308


## Dismantling

1. Remove the distributor from the engine 86.35.20.
2. Remove the distributor cap.
3. Remove the rotor arm.
4. Remove the dust cover.
5. Remove the felt pad from the top of the rotor.
6. Remove the two screws retaining the condenser and vacuum unit and remove the condenser lead from the connector block.
7. Remove the retaining clip from the eccentric 'D' post.
8. Mark the position of the serrated cam in relation to the spring seat of the vacuum operating link.
9. Disengage the vacuum operating link and serrated cam from the eccentric 'D' post and remove the vacuum unit.
10. Remove the retaining screw and withdraw the fixed contact plate.
11. Remove the retaining clip and insulation washer.
12. Release the connector block from the distributor body.
13. Lift out the moving contact complete with connector block and leads.
14. Mark the relationship of the base plate to the body and remove the retaining screw. Whilst holding the pressure pad clear of the rotor, withdraw the base plate.
15. Remove the moving contact post-plate.

## Inspection

**NOTE:** The distributor drive dog is loosely retained on the drive shaft, the "float" allows for any misalignment.

16. Examine the advance mechanism of the cam, check the shaft for excessive side play. If any of these parts are damaged or worn renew the complete distributor.
17. Examine all other components for damage or excessive wear and renew where necessary.
18. Check the distributor cover for signs of tracking or cracks and check that the pick-up brush moves freely in its holder.
19. Check the rotor arm for damage, electrode security, burning and tracking.

*Continued*



